



CCI handhole.

Existing fiber in duct.

Dig up existing duct and place approximately 20' of duct to building duct.

CCI handhole.

Existing fiber in duct.

Building Duct

Place fiber in existing building duct.

11725 95th Ave N

© 2018 Google

Google Earth