



Directional drill 250'

Place 2x3 vault

Storage

Pull through existing coax duct

Leave 150' coil at case

Storage

Enter bldg below grade using core drill and PVC.

Install 12ct 50' through acoustic ceiling to relay rack.

PTP and switch will be rack mounted.

there is drywall built in front of the entry point - may need to access through ceiling or drill through drywall to access

Nystrom Counseling - 13603 80th Cir N - Maple Grove 55369