



verify existing splice case location.

Bore (2) 1.5 inch pipe and pull new 12 count raw fiber from existing splice case location to new splice case location vault near new node location.

add vault with 100' storage and pull new opt. CIFA# 90243, to new node location. New splice case location

existing Wright Hemenway transformer

Bore (2) 1.5" pipe and pull new .860 from existing node to existing splitter ped location

No existing case at this location

add vault with 100' storage.

New node location. Replace old ped with new node ped.

Add PS cabinet at lot line and bury 1.5" conduit from new cabinet to transformer across road.