



ASBUILT

**Pull through
500' CIC/customer
conduit**

**Storage
SEQ1=
SEQ2=**

**Leave 100' coil
at case
SEQ=**

**Case
DC11**

**Case In
Vault
behind
sign. We
could not
find it. I
think its
buried**

**Building
MECH
Room**

**PV2 Install 2x3
ped/vault
SEQ1=
SEQ2=**

**Data
room**

**PV1 Install 2x3
Ped Vault
SEQ1=
SEQ2=**

**Existing duct used=
Pedvaults set=
vaults set=**

**V1 Install new 2x3 Vault
over viber duct and
Sweep to Ped Vault
SEQ 1=
SEQ 2=**

**12ct ID =
12ct @ PTP =
Jumper ID # =
ct @ PTP =
ct @ Rack =
Total ISP =
Copper used =**

**OSP pull 2835
ISP pull 160**

**Storage
SEQ1=
SEQ2=**

**Pull in
fiber duct**

**ME 020351
CFDI
9630 Grove Cir.
Maple Grove, MN 55369**

**Enter building through customer conduit into mechanical room.
Install PTP on wall in mech room. Install jumper 180ft through
acoustic ceiling to rack**

ASBUILT