



Need new co-locate cabinet installed.  
Bore (2) new 1.5" HDPE and pull new  
24ct fiber from here to new vault @  
Fieldstone Blvd.

Install new vault for fiber storage on lot  
line.

Get new vault for splice case and pull new  
12ct fiber to new node location.

New node location, install new cabinet.  
Trench (1) 1.5" conduit to Xcel  
transformer for power supply.