

**CONSTRUCTION NOTES:**  
 1. LOCATE ALL UTILITIES PRIOR TO DIGGING.  
 2. POT HOLE ALL BURIED UTILITY CROSSINGS.  
 3. RESTORE ALL SURFACES TO ORIGINAL OR BETTER CONDITION.  
 4. BORE 92' OF 4" PVC FROM EXISTING TEL HH TO EXISTING TEL HH.

