



*REPLACE
FAULTED
UNDERGROUND*

CAUTION!
DO NOT OPERATE SWITCHES
IF GENERATOR IS RUNNING.

CAUTION!
DO NOT OPERATE SWITCHES
IF GENERATOR IS RUNNING.

CAUTION!
DO NOT OPERATE SWITCHES
IF GENERATOR IS RUNNING.

MANHOLE - WARNING
CONFINED SPACE,
ENTRY PERMIT
REQUIRED

ALL TRANS. ARE OWNED BY BANTA

SUB 5 & 6 IS FED FROM SW-3

SUB 7 IS FED FROM SW-4

SUB 1 & 2 IS FED FROM SW-3

SUB 3 & 4 IS FED FROM SW-3

SUB 5, 6 & 7 ARE 2000KVA

REQUIRED

MANHOLE - WARNING
CONFINED SPACE,
ENTRY PERMIT
REQUIRED

SEPERATE TRENCH

SEPERATE TRENCH

SEPERATE TRENCH

SEPERATE TRENCH

SEPERATE TRENCH

SEPERATE TRENCH

SEPERATE TRENCH

SEPERATE TRENCH

SEPERATE TRENCH

SEPERATE TRENCH

SEPERATE TRENCH

SEPERATE TRENCH

Wright-Hennepin
Cooperative Electric Association
6800 ELECTRIC DRIVE - ROCKFORD, MN 55373
1 INCH = 251 FEET